

# COSTRUZIONE CABINE PER TRATTORI



[www.omgacabine.com](http://www.omgacabine.com)



**Modelli:**

- Antares 100 • ARGON 1° • ARGON 3 • Argon F • Aster
- Aurora • Bufalo 130 • Centauro 70 • Centurion 75 • Condor
- Corsaro • Delfino • Dorado • Dorado F • Drago 120
- Explorer 2° • Explorer 2°P • Explorer 75-85-95 T -85-95 TB
- Explorer Special 2° 70 80 90 • Explorer 65 70 • Falcon
- Frutteto 2 • Frutteto 3 • Golden • Jaguar • Laser
- Leopard 85 • Mercury • Mercury 85sp • Minitauro
- Panter 90 95 Sp • Ranger • Saturno Minitaurus 13/28 e 13/24
- SILVER • Sirenetta • Solaris • Solaris HD • Solor 50 60
- Solar 50 60 basso • Special Basso Explorer 65 70 75 80
- Special 1° tipo • Taurus Centauro • TIGER • Tiger Export • Trident



**Lamborghini**

**Modelli:**

- Runner • 235 • 345,483 • 583 • 503,603 • 550 • 660 • 654
- 684 • 600 • 700 • 653 • 674.5 • 674.70N • 774.5 • 774.80N
- 704 • 804 • 904 • 784 • 1106 • 1306 • 1506 • 754 • 854
- 955 • 1056 • Premium • R.1 • R.2 • R.3 • Crono F
- Crono Target • Agile • Crono • 554.50 • 564.60 • 574.70
- 574 • Target • 874390 Gran Prix • Formula 105 • Sprint
- Serie Cross 574.60N • 674.70N • EGO



**Modelli:**

- GM • CL • MB • C-MAX • X4M • X2



**Modelli:**

- Agriplus • Agrokid • Agrolux • Agrolux



**Modelli:**

- Advantage • Mistral • Rex • 5500 • 6500 • 6550 • 7500
- 7550 • 8550 • 10000 • 12500 • 13000 • 14500 • 5860
- 6860 • 7860 • 8860 • 6060 • 6030 • 6830 • 5830 • 4630
- 4645 • 4655 ISM-VRM-ARM • Legend • Powerfarm
- Technofarm • Globus • Globalfarm • Atlas • Atlantis • Legend



**Modelli:**

- Serie 3600 • Serie 1500 • Jupiter 40-45-50
- Serie 2500 • Serie 4500 • VP 4600 VRM / ISM / ARM

Via Locatelli, 29  
24053 BRIGNANO GERA D'ADDA  
BERGAMO • ITALY  
Tel. +39 0363 814031  
Fax +39 0363 816819

# COSTRUZIONE CABINE PER TRATTORI



[www.omgacabine.com](http://www.omgacabine.com)



## Modelli:

- Serie 254 • 264,274 • 690 • 675 • 698 • 353 • 363 • 373
- 383,393 • Serie 4200 • Serie 300 • Serie 4200 • Serie 3300

## Kubota

## Modelli:

- Serie B 2530 • 3030 • 2110, BX 2350 • 2650 • STW 37 • 40
- Serie L 3300 • 3600 • 4200 • 4100 • 3200 • 3540 • 4240
- 5040 • 5240 • 5740 • Serie M 6040 • 7040 • 8540 • 9540
- 8560 • 9560 • LP • MK 5000



## Modelli:

- Serie 10-Serie 15 • Serie 5000 • 6020 • 6205 • 6505
- 6320 • 6520 • Serie E • Serie M • Serie G -4600

## RENAULT

## Modelli:

- Celtis • Ceres



## Modelli:

- Serie 56 L.O.M. • Serie 66: 55 - 45 - 50 - 56 - 60 - 65
- 70 - 80 - 420 - 466 - 566 - 666 - 766 - 850 - 1000
- CONCORD 580 - 680 - 780 - 880 - 980 - 1300
- Super - 1180 - 1280 - 1380 - 1580 - 1880 • Serie 90: 100
- 115 - 130 - 140 - 160 • Serie 88 90 92 93 94: 60 - 65 - 70
- 80 - 90 - 100 - 110 - 420 - 480 - 500 - 540 - 640
- 640/ 8 e 12 marce • Serie TND -TLA- TNA - TN - TDD
- T 4000 - T 5000 TD 3.50 • DELUXE / STANDARD • TCE
- Serie 3000 • TD 4000 F • TD3.50 • BOOMER 50

## AGRIFULL

## Modelli:

- A40 • A50 • A50Lom • A65 • A70 • Derby • Griso
- Tornado • Rodeo • Serie 80 • A80 • 56 • 80 • 66 • 80
- 74 • A40 • A90 • A110 • A140

## DELEKS

## Modelli:

- TR 130 • 254 • 304 • 404 • 404 G2

## HÜRLIMANN

## Modelli:

- Prince - XF - XE F Tradition • XE 55 • 70 • XA Traditional
- XB • 468 • 358.4 • 468.4 • 468.4 Club



## Modelli:

- 254 • 304 • 404 • 404 G2

CABINE DA APPLICARE AL TELAIO DI SICUREZZA ORIGINALE DEL TRATTORE